




ONIKUMA

CW918

Indonesia

1. Sketsa produk



1. Tombol kiri


2. Tombol kanan

3. Tombol Gulir

4. Tombol maju

5. Tombol mundur

6. DPI



7. Tombol luntuk mengubah efek lampu.

8. Sakelar hidup,mati lampu.

2.Parameter produk

DPI bawaan: 1200 kuning/1600 biru/2400 merah muda
/3200 hijau/4800 merah/7200 cyan

Warna cahaya: RGB

Tegangan kerja: 5V

Antarmuka: USB

Arus kerja: $\leq 180\text{MA}$

Panjang kabel: 1.6M

Berat: 121g

Ukuran produk: 127*63*40 mm

3.Deskripsi Produk

- ➊ Penyesuaian kecepatan DPI: 6 tingkat penyesuaian DPI, hingga 7200 DPI;
- ➋ Lampu RGB: 13 efek pencahayaan yang dapat dipilih
- ➌ Fungsi jempol cepat: maju atau mundur saat menjelajahi halaman web, maju atau mundur di folder yang sama;
- ➍ Mouse game optik 7 tombol: kiri/kanan/tengah/depan, mundur/DPI/ganti efek cahaya;
- ➎ Sakelar lampu: tekan tombol "7" di bagian bawah untuk mengganti warna lampu;

- ⑥ Kompatibilitas sistem: Windows 98/2000/ME/NT/XP/
Win 7 / Win 8 / Win 10 / Mac OS dan OS lainnya,

4. Tindakan pencegahan

Penggunaan yang tidak tepat dapat merusak mouse, jadi harap perhatikan hal-hal berikut :

1. Hindari penggunaan mouse pada permukaan kasar (seperti karpet dan kayu kasar);
2. Jangan membenturkan mouse;
3. Jangan gunakan mouse di bawah temperatur tinggi dan paparan cahaya yang terlalu kuat;
4. Jauhkan tetikus dari cairan.






ONIKUMA

CW918

English

1.Product sketch



1. Left button


2. Right button

3. Roller/Middle button

4. Forward

5. Backward

6. DPI cycle



7.Lighting effect
switch button

8.On/Off RGB toggle

2.Product parameters

Default DPI:	1200 Yellow/1600 Blue/2400 Pink/ 3200 Green/4800 Red/7200 Cyan
Light Color:	RGB
working Voltage:	5V
Interface:	USB
working Current:	Less than 180MA
Cable length:	About 1.6M
Weight:	Around 121g
Product dimension:	127*63*40mm

3.Product manual

- ① Adjustable DPI speed: 6-stage DPI adjustment, up to 7200DPI;
- ② RGB light: 13 light effects can be switched
- ③ 7-button optical gaming mouse: left/right/middle/forward/backward/DPI cycle/light effect switch.
- ④ Quick thumb function: Go forward or backward when you are browsing the web, Go forward or backward in the same folder window;
- ⑤ Light switch: press the button "7" at the bottom to switch light;

Light switch: press and hold the "Roller/Middle "button, then simultaneously press "DPI+"button to switch;

- 5** Compatible System: Windows 98/ 2000/ ME/ NT / XP/ Win7/ Win 8/ Win 10/ Mac OS and other OS, plug & play.

4. Matters needing attention

incorrect use will damage the mouse, so please pay attention to the following usage points:

- 1.Avoid using the mouse on surfaces with low finish such as carpets, and rough wood.
- 2.Do not bump the mouse
- 3.Do not use the mouse under high temperature and strong light
- 4.Do not put the mouse in the liquid The mouse light is on.

